

Proper Gripper Pod Placement



- Positioning the the gripper pods properly on your 500 Series Curling Shoes will prolong the life of your gripper pods.
- Place the front gripper pod approximately 1/8" back from the toe of the shoe.

Closeup View



1/8" back from toe

This positioning with the correct hack foot position (<https://www.balanceplus.com/hackfoot.pdf>) will maximize the life of your gripper pods.